

FIG. 1

+




FIG. 2

+




FIG. 3

+




FIG. 4




FIG. 5

+





FIG. 6

Replacement Sheet






FIG. 8

+




FIG. 9

APC Back-UPS HS 500 - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Back Search Favorites Media W

Address http://159.215.32.160/

APC
www.apc.com

APC Back-UPS HS 5

Status Configuration Maintenance Logoff

Battery Self Test

Test Now 90

Test results are displayed on the status page.

Update Battery Replacement Date

Update Now 92

Perform this operation only upon battery replacement.

Change Username and Password

Enter New Username

Enter New Password

Valid entries are 20 or lower characters in length.

Update Now

Restore Factory Defaults 94

Restore Now

Restore battery backup comings back to then factory default value:

Maintenance Page

Maintenance Page

Internet

FIG. 10




FIG. 11




FIG. 12




FIG. 13